

Installation

Windows

The Windows-SETUP Program is located here: [HSmodem V0.87 Windows](#)

Download the current Windows version "hsmodem_Setup.exe" from the link above and install it. NO changes are made to Windows. The setup program only copies the files to the hard drive and creates the links in the start menu.

The user interface can be found in the start menu under "Amsat" - "hsmodem" and can be started. Windows 10: After the first start, Windows 10 shows two dialogs to obtain permission for network access. You have to confirm both, otherwise the program won't run.

DLLs: if a message about missing DLLs appears when the program starts (msvcp140.dll and others), the Microsoft package: vc_redist.x86.exe must be installed. Please only use the original from Microsoft, this is located here:


<https://support.microsoft.com/de-de/help/2977003/the-latest-supported-visual-c-downloads>

and the short link to this page:

<https://t1p.de/b68y>


ATTENTION: ALWAYS select the x86 version (vc_redist.x86.exe) even if you have a 64bit PC!

Successful installation and functioning network access can be recognized in the status line by the network address of the modem being displayed (here an example):



Modem-IP: 192.168.0.2

if the network access failed, you can see:



Modem-IP: ?

From:

<https://wiki.amsat-dl.org/> - **Satellite Wiki**

Permanent link:

<https://wiki.amsat-dl.org/doku.php?id=en:hsmodem:installwin>

Last update: **2022/05/16 01:00**

